

BACKPACK SPRAYER MAINTENANCE

AVOID SPILLAGE AND LEAKS

1.

Check the condition of the hose

2.

Check and replace hose clamps that are damaged

3.

Check and replace gaskets that are damaged

4.

Check the operation of the shutoff valve

5.

Choose the appropriate nozzle. Replace nozzle if damaged

6.

Lubricate the piston seal with light oil

7.

Wash the sprayer after using it

8.

Check and replace any damaged valves

THE BENEFITS OF AVOIDING LEAKS IN THE SPRAYER ARE:

- ✔ Saves you money; does not waste product. Reduces
- ✔ the risk of skin exposure.
- ✔ Reduces the risk of environmental contamination.

